


**BOSCH**

HES642HDK/01-V01, weiss
HES642HDK/02-V02, weiss
HES642HDK/03-V03, weiss

HERDE
Stand-Herde



Ident – Nummern – Konstante
3740

Gebrauchsanweisung
51 5951
(DK)

Bratzeitautomatik–
Tabelle
51 3533
(S,N,SF,DK)

Zubehör:

HEZ14BB
Alu-Backblech

HEZ21BB
Backblech emailliert

HEZ16BP
Bratpfanne

HEZ16KP
Universalpfanne

HEZ10SP
Spritzschutzpfanne

HMZ21GB
Glasbräter




BOSCH

HES642HDK/01-V01, weiss
HES642HDK/02-V02, weiss
HES642HDK/03-V03, weiss

HERDE
Stand-Herde

Ident – Nummern – Konstante
3740

- 1) 04 4473
- 2) 02 9703




**BOSCH**

HES642HDK/01-V01, weiss
HES642HDK/02-V02, weiss
HES642HDK/03-V03, weiss

HERDE
Stand-Herde

Ident - Nummern - Konstante
3740






BOSCH

HES642HDK/01-V01, weiss
HES642HDK/02-V02, weiss
HES642HDK/03-V03, weiss

HERDE
Stand-Herde

Ident - Nummern - Konstante
3740

- 1) 02 8633
- 2) 02 8634
- 3) 05 7021



**BOSCH**

HES642HDK/01-V01, weiss
 HES642HDK/02-V02, weiss
 HES642HDK/03-V03, weiss

HERDE
 Stand-Herde

