


Ersatzteil-Liste

GAGGENAU

Elektrokochfläche

KE 272-104/124/127/134 - 144/154/164/174 - 194 - KE 272-114

03/93



Stueckliste E630266

KE272104	KE272114	KE272124	KE272127	KE272128	KE272154	KE272158
KE272164	KE272174	KE272194	KE272204	KE272214	KE272224	KE272227
KE272254	KE272264	KE272294	KE272514	KE272524	KE272594	KE272627
KE272658						

Pos.	Mat-Nr.	Bezeichnung	Description
1	322153	Abstandsbolzen vorn	distance bolt front
2	321307	Abstandsbolzen hinten	distance bolt rear
3	155642	Achsverlaengerung	achsel prolongation
4	291985	Anschlussblech	connection panel
5	321427	AnschlusKlemme	terminal block
6	097728	Autom. Kochplatte 145 mm , 220 V	autom. cooking plate 145 mm, 220 V
	097729	Autom. Kochplatte 145 mm, 380 V	autom. cooking plate 145 mm, 380 V
	098153	Autom. Kochplatte 145 mm, 240 V	autom. cooking plate 145 mm, 240 V
7	097726	Autom. Kochplatte mm 180, 220 V	autom. cooking plate mm 180, 220 V
	097727	Autom. Kochplatte mm 180, 380 U	autom. cooking plate mm 180, 380 V
	097730	Autom. Kochplatte mm 180, 240 V	autom. cooking plate 180 mm , 240 V
8	292422	Befestigungs.- u. Abschirmblech AP 145 mm	fixing + deflector panel f. AP 145 mm
9	320911	Befestigungs- u. Abschirmblech AP mm 180	fixing + deflector panel f. AP mm 180
10	292423	Befestigungs- u. Abschirmblech AP 180 mm	fixing + deflector panel f. AP mm 180
11	292424	Befestigungs- u. Abschirmblech NP mm 220	fixing + deflector pane f. NP mm 220
12	156410	Bimetall-Scheiben-	bimetal thermostat
13	097717	Blitzkochplatte mm 180, 220 V	fast heating plate mm 180, 220 V
	097736	Blitzkochplatte mm 180, 380 V	fast heating plate mm 180, 380 V
	097737	Blitzkochplatte mm 180, 240 V	fast heating plate mm 180, 240 V
14	211482	Bodenblech (Emailmulden)	base plate (enam. hobs)
14a	211483	Bodenblech geschw. f. Edelstahlmulden	base plate welded f. stainless steel hobs
15	-----	Dichtungsband vorn	gasket band front
16	-----	Dichtungsband hinten	gasket band rear
17	097825	7-Takt-Drehschalter	7-position switch
18	210936	Gehaeusewanne mit Muldenspanner	housing with fixing clips
19	098099	Kabelbaum	wiring harness
20	156591	Knebel	knsb
21	156511	Kontrolleuchte 220/240 V	control lamp 220/240 V
	156512	Kontrolleuchte 380 V	control lamp 380 V
22	156390	AP-Regler	automatic control
23	097060	Messingdraht 1,5 d, 150	earth wire 1,5 d, 150
24	211396	Mulde Edelstahl	hob, stainless steel
	210678	Mulde weiss emailliert	hob, white enamelled
	210679	Mulde mokka emailliert	hob, mokka enamelled
	210680	Mulde sand emailliert	hob, sand enamelled
	210681	Mulde beige emailliert	hob, beige enamelled
	210682	Mulde rot emailliert	hob, red enamelled

Stueckliste E630266

KE272104	KE272114	KE272124	KE272127	KE272128	KE272154	KE272158
KE272164	KE272174	KE272194	KE272204	KE272214	KE272224	KE272227
KE272254	KE272264	KE272294	KE272514	KE272524	KE272594	KE272627
KE272658						

Pos.	Mat-Nr.	Bezeichnung	Description
24	210683	Mulde agave emailliert	hob, agave enamelled
	210684	Mulde majolika emailliert	hob, majolika enamelled
	210686	Mulde brasil emailliert	hob, brezil enamelled
25	097711	Normalkochplatte mm 220, 220 V	normal cooking plate mm 220, 220 V
	097714	Normalkochplatte mm 220, 380 V	normal cooking plate mm 220, 380 V
	097734	Normalkochplatte mm 220, 240 V	normal cooking plate mm 220, 240 V
26	097166	Schalterblende kpl. bestehend aus:	switch control panel com including:
	291204	Schalterblende	1 switch board panel
	156012	Endstueck rechts	1 end piece right
	156013	Endstueck links	1 end piece left
26a	097880	Blendeneinlage	insert
27	321419	Schaltertraeger	switch holder
28	320857	Senkschraube	countersunk screw
29	156378	Zugentlastung	cable clamp