





Mat. - Nr. - Konstante  
3740 . . . . .  
Gebrauchsanweisung  
52 9303  
(D,GB,F,I,NL,TR)

Ident – Nummern – Konstante  
3740 . . . . .



|      | V01                | V02                 |  |
|------|--------------------|---------------------|--|
| Pos. | Zanussi<br>HLY75AA | Danfoss<br>TLES8KK2 |  |
| 1    | 14 2049            | 14 2049             |  |
| 2    |                    |                     |  |
| 3    | 18 4226            | 15 1055             |  |
| 4    |                    |                     |  |
| 5    | 15 3080            | 15 0760             |  |
| 6    | 15 3079            | 15 1072             |  |
| 7    |                    |                     |  |
| 8    |                    |                     |  |
| 9    | 15 3069            | 15 3069             |  |
| 10   |                    |                     |  |
| 11   |                    |                     |  |
| 12   |                    |                     |  |
| 13   |                    |                     |  |

| TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES |                    |                     |  |
|--------------------------------------------------------|--------------------|---------------------|--|
| Verdichter/Compressor/Compresseur                      | Zanussi<br>HLY75AA | Danfoss<br>TLES8KK2 |  |
| Typ/Type                                               |                    |                     |  |
| Förderleistung/Delivery/Débit                          | l/h                |                     |  |
| Anlaufstrom/Starting current/Cour de démarrage         | A                  |                     |  |
| Widerstand/Resistance/Résistance Ha/main/prin          | Ω                  |                     |  |
| Hi/aux                                                 | Ω                  |                     |  |
| Temp.-Regler/Thermostat                                |                    |                     |  |
| Typ/Type                                               |                    |                     |  |
| Regelstellung/Position                                 |                    |                     |  |
| Schaltwerte/Switching values                           | "warm"             |                     |  |
| Valeurs de commutation                                 | "kalt"             |                     |  |
|                                                        | "alarm"            |                     |  |
| Füllmenge/Fill.quantity/Charge                         | R600a              |                     |  |
| Anschlußwert/Conn.load/Puiss. connectée                | W                  |                     |  |
| Heizung/Heater/Chauffage                               |                    |                     |  |
| Widerstand/Resistance/Résistance                       | Ω                  |                     |  |
| Leistung/Power/Puissance                               | W                  |                     |  |
| Ventilator/Blower/Ventilateur                          |                    |                     |  |
| Widerstand/Resistance/Résistance                       | Ω                  |                     |  |
| Temp.-Regler/Thermostat                                |                    |                     |  |
| Magnetventil/Magnetic valve/Electrovanne               |                    |                     |  |
| Widerstand/Resistance/Résistance                       | Ω                  |                     |  |
| Spannung/Voltage/Tension                               | V                  |                     |  |