



BOSCH

SMS 2100 – 0 730 103 503–DK

GESCHIRRSPÜLGERÄTE
Standgeräte


Ident-Nummern-Konstante
3740


51 2832

DK1


Gebrauchsanweisung
(D,GB,F,I,NL,DK,P,E)

51 1381/00
Aufstellanleitung




Ident-Nummern-Konstante
3740

- 1) 08 0781/02
Set
- 2) 02 5067/01
Set
- 3) 01 9204/02
Set
- 4) 14 0283/37
220 V, 50 Hz
02 5606/05
Relais
- 5) 14 0175/37
220 V, 50 Hz
08 0783/16
10 μ F
- 6) 20 2292/19
1700 W
- 7) 08 3501/19
1300 W

Ident-Nummern-Konstante
3740

**BOSCH**

SMS 2100 — 0 730 103 503—DK

GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740

**BOSCH**

SMS 2100 — 0 730 103 503—DK

GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740

1) 01 9202/01/4

2) 11 0668/07
Set3) 05 1287/03
Set4) 20 0794/33
bis FD 6408
20 2683/33
ab FD 6409