


2NF1624-5-V01
2NF1624-5/01-V07
2NF1634-5-V02
2NF1634-5/01-V08

2NF1644-5-V03
2NF1644-5/01-V09
2NF1654-5-V04
2NF1654-5/01-V10

2NF1664-5-V05
2NF1664-5/01-V11
2NF1664-5E-V0
2NF1664-5E/01-V12



Gebrauchs- und
Montageanweisung
51 8280

Lackstift sepiaweiß
31 0351

- 1) 21 0496
V02,V08,625W/12,8h
21 0499
V03,V09,750W/10,6h
21 0502
V04,V10,875W/9h
21 0504
V05,V06,V11,V12
1000W/8h
- 2) 21 0496
V02,V08,625W/12,8h
21 0499
V03,V09,750W/10,6h
21 0502
V04,V10,875W/9h
21 0504
V05,V11,1000W/8h
21 2113
V06,V12,1250W/8h

Zubehör:

Einbau-Raum-
temperaturregler
2NF1881
2NF1882
Zusatzheizung
2NF1821
2NF1822
Ergänzungssatz
Zweikreisspeicher
2NF1825