












0199



0195







TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör Typ/Type/Tip Förderleistung/Delivery/Verim/h Anlaufstrom/Starting current/Giris akimi A Widerstand/Resistance/Rezistans Ha/ Ohm Hi/aux.	JIA XIPERA NT1113Y		
Temp.Reyler/Thermostat/Termostat Typ/Type/Tip Reglerstellung/Position/Termostat pozisyonu Schaltwerte/Acma kapama degerleri ..ein/acma °C Valeurs de commutation/Termostat degeri ..aus"/kapama (..abtaven' od) ..alarm'			
Füllmenge/Fill. quantily/ Dolum miktari R600a g	98		
Anschlusswert/Comm. load/Giris gucu W	*		
Heizung/Heater/Rezistans Widerstand/Resistance/Direnc Ohm Leistung/Power/Guc W			
Ventilador/Blower/Vantilatör Widerstand/Resistance/Rezistans Ohm			
Magnetventil/Magnetic valve/Manyetik valf Widerstand/Resistance/Rezistans Ohm Spannung/Voltage/Gerilim V			
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakiniz