





Gebrauchsanweisung
58 2102
(en,de,fr,it,es,pt,nl)

1) 17 2346

2) 18 9685
V01,V05
18 9684
V02,V06
18 9686
V03,V07
41 6576
V04,V08

3) 18 9653
V01,V05
18 4785
V02,V04
V06,V08
18 8549
V03,V07



- 1) 18 8360
- 2) 18 8361
- 3) 18 8359

Düsensatz Für:

Flussigas 28 mbar:
18 7479
Erdgas 20 mbar
41 6374
Flussigas 50 mbar
41 6687