





Gebrauchsanweisung  
58 1384 (de)

Montageanweisung:  
52 4061  
(de,en,fr,it,nl,da,sv,no,  
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:  
HZ21004  
Backblech Alu  
HZ21101  
Backblech emailliert  
HZ21301  
Universalpfanne  
HZ21401  
Kombirost  
HZ22400  
Einlege-Kombirost  
HZ22500  
Grillblech  
HZ9150  
Glasbraeter  
HZ26000  
Metallbraeter

1) 01 4254



1) 48 2981  
Set

